## data sheet

# elcometer

### Elcometer 2215 Lory Viscosity Cup



Elcometer 2215 Lory Viscosity Cup

### At a glance:

Needle fixed to the bottom for quick measurements

When the needle point appears, the flow time has elapsed

A conventional cylindrical cup with a needle fixed into the bottom for quick measurements on-site or during production.

The cup is first dipped into the product to be measured, then empties through the escape hole.

Unlike other viscosity cups, the flow time is measured as soon as the point of the needle appears.

### ppears.

### Part Number Description Cup No. Range (cSt)<sup>1</sup> K0002215M001 Elcometer 2215 Lory Cup 1 50 – 1100

For information only

### Viscosity

The extent to which a liquid resists a tendency to flow is defined as viscosity. In the coatings industry, this behaviour is one of the key parameters.

Elcometer manufactures and supplies a wide range of viscosity gauges from flow cups and dip cups to rotational viscometers

Flow Cups: The process of flow through an orifice can often be used as a relative measurement and classification of viscosity. This measured kinematic viscosity is generally expressed in seconds of flow time which can be converted into Centistokes using a viscosity disc calculator.

Dip Cups: Using the same principle to the flow cups, dip cups – Frikmar, Zahn, Shell, etc – can be used to provide a quick viscosity measurement on the shop floor or on site

Rotational: Rotational viscometers are used to determine the viscosity of liquids which do not depend solely on temperature and pressure. The behaviour of non-Newtonian liquids can be determined using a range of rotational viscometers.

## data sheet

### elcometer

### **Related Products**



Elcometer 7300 Stopwatch

#### Elcometer 7300 High Precision Stopwatch:

Measuring intervals: 1/100 second for 30 minutes and 1 second for 24 hours. Time / calendar display, 12/24 hour mode.

Part Number: K0007300M201

#### ENGLAND

Elcometer Ltd Edge Lane Manchester M43 6BU

Tel: +44 (0)161 371 6000 Fax: +44 (0)161 371 6010 e-mail: sales@elcometer.com www.elcometer.com

USA

Elcometer Inc 1893 Rochester Industrial Drive Rochester Hills Michigan 48309

Tel: +1 248 650 0500 Toll Free: 800 521 0635 Fax: +1 248 650 0501 e-mail: inc@elcometer.com www.elcometer.com

CANADA

Elcometer Ltd PO Box 622, 401 Ouelette Avenue Windsor, Ontario N9A 6N4

Tel: +1 248 650 0500 Toll Free: 800 521 0635 Fax: +1 248 650 0501 e-mail: ca\_info@elcometer.com www.elcometer.com

#### ASIA & THE FAR EAST

Elcometer (Asia) Pte Ltd 896 Dunearn Rd Sime Darby Centre #3-09 Singapore 589472, Republic of Singapore

Tel: +65 6462 2822 Fax: +65 6462 2860 e-mail: asia@elcometer.com www.elcometer.com

BELGIUM

Elcometer SA Rue Vallée 13 B-4681 Hermalle /s Argenteau

Tel: +32 (0)4 379 96 10 Fax: +32 (0)4 374 06 03 e-mail: be\_info@elcometer.be www.elcometer.be

FRANCE

Elcometer Sarl 97 Route de Chécy 45430 BOU

Tel: +33 (0)2 38 86 33 44 Fax: +33 (0)2 38 91 37 66 e-mail: fr\_info@elcometer.fr www.elcometer.fr

#### GERMANY

Elcometer Instruments GmbH Ulmer Strasse 68 D-73431 Aalen

Tel: +49 (0)7361 52806 0 Fax: +49 (0)7361 52806 77 e-mail: de\_info@elcometer.de www.elcometer.de